


FRONT FOG LIGHT



SERVICE HINTS

FR FOG RELAY

3-5 : Closed with the light control SW at **HEAD** position, the dimmer SW at **LOW** position and the front fog light SW at **ON** position

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C11	34	F2	32		
F1	32	J5	35		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room No.1 R/B (Engine Compartment Right)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2A	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2B		
2F	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
EC	42	Left Fender Apron
ID	44	Cowl Side Panel LH
IH	44	Cowl Side Panel RH