


FROM POWER SOURCE SYSTEM (SEE PAGE 56)



SERVICE HINTS

R13 REMOTE CONTROL MIRROR SW

- 1-3 : Continuity with the operation SW at **DOWN** or **RIGHT** position
- 3-4 : Continuity with the operation SW at **UP** or **LEFT** position
- 1-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position
- 4-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J5	35	R11	37 (S/D)	R12	39 (W/G)
J11	36 (S/D)		39 (W/G)	R13	37 (S/D)
	38 (W/G)	R12	37 (S/D)		39 (W/G)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	24	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1L	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID2	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
II1	46	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	42	Left Fender Apron
ID	44	Cowl Side Panel LH