



POWER SOURCE





POWER SOURCE

SERVICE HINTS

HEAD LP RELAY

2-1 : Closed with the light control SW at **HEAD** position or the dimmer SW at **FLASH** position

DIMMER RELAY

1-2 : Closed with the light control SW at **HEAD** position and the dimmer SW at **HIGH** position

Closed with the dimmer SW at **FLASH** position

Closed with the daytime running light operation

TAIL RELAY

3-5 : Closed with the light control SW at **TAIL** or **HEAD** position

I12 IGNITION SW

2-3 : Closed with the ignition key at **ACC** or **ON** position

2-4 : Closed with the ignition key at **ON** or **ST** position

7-6 : Closed with the ignition key at **ON** or **ST** position

7-8 : Closed with the ignition key at **ST** position

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
I12	35				

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room No.1 R/B (Engine Compartment Right)
2	22	Engine Room No.2 R/B (Engine Compartment Right)
3	23	Engine Room No.3 R/B (Engine Compartment Left)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1H		
1O	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2C	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2H	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2M	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	44	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)

