


AUTOMATIC GLARE-RESISTANT EC MIRROR



SERVICE HINTS

I14 INNER MIRROR

- 1-GROUND : Approx. **12** volts with the ignition SW at **ON** position
- 4-GROUND : Always continuity

○ : PARTS LOCATION

| Code | See Page | Code | See Page | Code | See Page |
|------|--------------------------|------|--------------------------|------|--------------------------|
| I14 | 36 (S/D) | R11 | 39 (W/G) | W4 | 37 (S/D) |
| | 38 (W/G) | R12 | 37 (S/D) | | 39 (W/G) |
| R11 | 37 (S/D) | | 39 (W/G) | | |

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

| Code | See Page | Junction Block and Wire Harness (Connector Location) |
|------|--------------------|---|
| 1A | 24 | Instrument Panel Wire and Driver Side J/B (Left Kick Panel) |
| 1N | 24 | Roof Wire and Driver Side J/B (Left Kick Panel) |

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location) |
|------|--------------------|---|
| ID2 | 44 | Front Door LH Wire and Instrument Panel Wire (Left Kick Panel) |
| II1 | 46 | Front Door RH Wire and Instrument Panel Wire (Right Kick Panel) |
| IJ1 | 46 | Roof Wire and Floor No.2 Wire (Left Side of the Instrument Panel) |

▽ : GROUND POINTS

| Code | See Page | Ground Points Location |
|------|--------------------------|------------------------|
| BJ | 48 (S/D) | Front Floor Panel LH |
| | 50 (W/G) | |

○ : SPLICE POINTS

| Code | See Page | Wire Harness with Splice Points | Code | See Page | Wire Harness with Splice Points |
|------|--------------------|---------------------------------|------|----------|---------------------------------|
| I7 | 46 | Instrument Panel Wire | | | |