



POWER SEAT

FROM POWER SOURCE SYSTEM (SEE PAGE 56)





POWER SEAT

SERVICE HINTS

P16 POWER SEAT CONTROL SW (DRIVER'S SEAT)

1-GROUND : Always approx. 12 volts

4-GROUND : Always continuity

P17 POWER SEAT CONTROL SW (FRONT PASSENGER'S SEAT)

1-GROUND : Always approx. 12 volts

4-GROUND : Always continuity

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
P16	40	P20	40	P24	40
P17	40	P21	40	P25	40
P18	40	P22	40		
P19	40	P23	40		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room No.1 R/B (Engine Compartment Right)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
2G	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2I		
2M	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB3	44	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
IH4	46	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
BG1	52	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)
BH1	52	Floor Wire and Front Seat RH Wire (Under the Front Passenger's Seat)

: GROUND POINTS

Code	See Page	Ground Points Location
BJ	48 (S/D)	Front Floor Panel LH
	50 (W/G)	
BK	48 (S/D)	Front Floor Panel RH
	50 (W/G)	

