



CHARGING





CHARGING

SERVICE HINTS

G1 (A), G2 (B) GENERATOR

- (A) 1-GROUND : **13.8–15.0** volts with the engine running at **5000** rpm and **25°C (77°F)**
13.2–14.0 volts with the engine running at **5000** rpm and **115°C (239°F)**
 (B) 1-GROUND : Below **1.5** volts with the ignition SW at **ON** position and engine not running

○ : PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
A12	A	34	D6		34	J1	A	33
A13	B	34	E4	B	32	J2	B	33
B6	B	34	E6	D	32	T6		35
C9	A	34	G1	A	32			
C10	B	34	G2	B	32			

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room No.1 R/B (Engine Compartment Right)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1K	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2H	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
IA3	44	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IE	44	Front Floor Panel Center LH

