


# COMPASS

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



## SERVICE HINTS

### I14 COMPASS [INNER MIRROR]

1-GROUND : Approx. **12** volts with the ignition SW at **ON** position

4-GROUND : Always continuity

## : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
I14	<a href="#">36 (S/D)</a>	W4	<a href="#">37 (S/D)</a>		
	<a href="#">38 (W/G)</a>		<a href="#">39 (W/G)</a>		

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1N	<a href="#">24</a>	Roof Wire and Driver Side J/B (Left Kick Panel)

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IJ1	<a href="#">46</a>	Roof Wire and Floor No.2 Wire (Left Side of the Instrument Panel)

## : GROUND POINTS

Code	See Page	Ground Points Location
BJ	<a href="#">48 (S/D)</a>	Front Floor Panel LH
	<a href="#">50 (W/G)</a>	