


# HORN

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



---

## SERVICE HINTS

### HORN RELAY

5-3 : Closed with the horn SW on

### : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C12	<a href="#">34</a>	H13	<a href="#">33</a>	H14	<a href="#">33</a>

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	<a href="#">22</a>	Engine Room No.1 R/B (Engine Compartment Right)
2	<a href="#">22</a>	Engine Room No.2 R/B (Engine Compartment Right)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
2G	<a href="#">26</a>	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2M	<a href="#">26</a>	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)