


CLOCK



SERVICE HINTS

A12 CLOCK [A/C CONTROL ASSEMBLY]

- 8-GROUND : Always approx. **12** volts (Power for clock)
- 7-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position (Power for indication)
- 18-GROUND : Always continuity

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A12	34	J10	35		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2I	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
IH	44	Cowl Side Panel RH