



J POWER SOURCE (Current Flow Chart)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other Parts.



[LOCATION] ① : Engine Room No.1 R/B (See Page 22) ② : Engine Room No.2 R/B (See Page 22)
 ⑤ : Engine Room No.3 R/B (See Page 23)



③ : Driver Side J/B (See Page 24)

④ : Passenger Side J/B (See Page 26)

J POWER SOURCE (Current Flow Chart)

Engine Room No.1 R/B (See Page 22)

Fuse		System	Page
7.5A	ABS2	ABS and Traction Control	216
		VSC	210
7.5A	ALT-S	Charging	64
7.5A	DRL NO.1	Headlight	82
10A	HORN	Horn	240
		Theft Deterrent	186
15A	ETCS	Cruise Control	202
		Electronically Controlled Transmission and A/T Indicator	196
		Engine Control	68
15A	H-LP L LWR	Front Fog Light	88
		Headlight	82
15A	H-LP R LWR	Headlight	82
15A	TURN-HAZ	Turn Signal and Hazard Warning Light	92
20A	AM2	Engine Control	68
		Starting and Ignition	60
20A	RADIO NO.1	Radio and Player (S/D)	260
		Radio and Player (W/G)	264
25A	EFI	Cruise Control	202
		Electronically Controlled Transmission and A/T Indicator	196
		Engine Control	68
		Engine Immobiliser System	80
30A	CDS FAN	Radiator Fan and Condenser Fan	280
30A	DRL NO.2	Headlight	82
30A	H-LP CLN	Headlight Cleaner	122
30A	P/SEAT	Power Seat	248
30A	RDI FAN	Radiator Fan and Condenser Fan	280
40A	MAIN	Automatic Light Control	112
		Headlight	82
		Headlight Cleaner	122
		Light Auto Turn Off	116
		Starting and Ignition	60
		Theft Deterrent	186
60A	ABS1	ABS and Traction Control	216
		VSC	210
120A	ALT	Automatic Light Control	112
		Charging	64
		Illumination	94
		Light Auto Turn Off	116
		Multiplex Communication System	138
		Power Window	168
		Rear Window Defogger and Mirror Heater	270

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
120A	ALT	Taillight (S/D)	98
		Taillight (W/G)	102
		Theft Deterrent	186

Engine Room No.2 R/B (See Page 22)

Fuse		System	Page
10A	H-LP L UPR	Headlight	82
10A	H-LP R UPR	Headlight	82

Driver Side J/B (See Page 24)

Fuse		System	Page
7.5A	PANEL	Combination Meter	274
		Illumination	94
		Multiplex Communication System	138
		Rear Fog Light	90
7.5A	STARTER	Electronically Controlled Transmission and A/T Indicator	196
		Engine Control	68
		LEXUS Navigation System	254
		Starting and Ignition	60
10A	A/C	Automatic Air Conditioning	284
10A	ECU-IG	ABS and Traction Control	216
		Automatic Air Conditioning	284
		Automatic Glare-Resistant EC Mirror	236
		Automatic Light Control	112
		Compass	238
		Cruise Control	202
		Door Lock Control and Wireless Door Lock Control	176
		Headlight	82
		Headlight Beam Level Control	126
		Interior Light	154
		Key Reminder and Seat Belt Warning	162
		LEXUS Navigation System	254
		Light Auto Turn Off	116
		Moon Roof	228
		Multiplex Communication System	138
		Power Window	168
		Radiator Fan and Condenser Fan	280
		Shift Lock	232
10A	GAUGE	Theft Deterrent	186
		VSC	210
		ABS and Traction Control	216
		Back-Up Light	110
		Charging	64
		Combination Meter	274

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
10A	GAUGE	Cruise Control	202
		Electronically Controlled Transmission and A/T Indicator	196
		Engine Control	68
		Front Window Deicer	268
		Headlight	82
		Headlight Beam Level Control	126
		Interior Light	154
		Key Reminder and Seat Belt Warning	162
		LEXUS Navigation System	254
		Multiplex Communication System	138
		Power Window	168
		Rear Window Defogger and Mirror Heater	270
		Shift Lock	232
		Stop Light (S/D)	106
		Stop Light (W/G)	108
		Taillight (S/D)	98
		Taillight (W/G)	102
		Turn Signal and Hazard Warning Light	92
		VSC	210
10A	RADIO NO.2	Automatic Air Conditioning	284
		Cigarette Lighter and Power Outlet	242
		Clock	244
		Door Lock Control and Wireless Door Lock Control	176
		Interior Light	154
		Key Reminder and Seat Belt Warning	162
		LEXUS Navigation System	254
		Light Auto Turn Off	116
		Multiplex Communication System	138
		Power Window	168
		Radio and Player (S/D)	260
		Radio and Player (W/G)	264
		Remote Control Mirror	246
		Shift Lock	232
		Theft Deterrent	186
10A	SRS-ACC	SRS	223
10A	TAIL	Taillight (S/D)	98
		Taillight (W/G)	102
15A	CIG	Cigarette Lighter and Power Outlet	242
15A	SEAT HTR	Seat Heater	252
15A	STOP	ABS and Traction Control	216
		Cruise Control	202
		Electronically Controlled Transmission and A/T Indicator	196
		Engine Control	68
		Shift Lock	232

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
15A	STOP	Stop Light (S/D)	106
		Stop Light (W/G)	108
		VSC	210
15A	WASHER	Front Wiper and Washer	130
		Headlight Cleaner	122
		Rear Wiper and Washer	134
20A	D FR P/W	Multiplex Communication System	138
		Power Window	168
20A	DOOR	Back Door Opener	194
		Door Lock Control and Wireless Door Lock Control	176
		Interior Light	154
		Key Reminder and Seat Belt Warning	162
		Light Auto Turn Off	116
		Multiplex Communication System	138
		Power Window	168
		Theft Deterrent	186
20A	FR DEF	Front Window Deicer	268
25A	WIPER	Front Wiper and Washer	130
		Rear Wiper and Washer	134
30A	S/ROOF	Moon Roof	228
40A	RR DEF	Rear Window Defogger and Mirror Heater	270

Passenger Side J/B (See Page 26)

Fuse		System	Page
7.5A	DOME	Door Lock Control and Wireless Door Lock Control	176
		Garage Door Opener	234
		Interior Light	154
		Light Auto Turn Off	116
		Multiplex Communication System	138
		Theft Deterrent	186
7.5A	ECU-B2	Automatic Light Control	112
		Headlight	82
		Light Auto Turn Off	116
		Rear Fog Light	90
		Theft Deterrent	186
		VSC	210
7.5A	IGN	Cruise Control	202
		Electronically Controlled Transmission and A/T Indicator	196
		Engine Control	68
		Engine Immobiliser System	80
		SRS	223
7.5A	OBD	Cruise Control	202
		Electronically Controlled Transmission and A/T Indicator	196
		Engine Control	68

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
7.5A	SRS-B	Combination Meter	274
		Interior Light	154
		Multiplex Communication System	138
		SRS	223
7.5A	TV	LEXUS Navigation System	254
10A	MPX-B	Automatic Air Conditioning	284
		Back Door Opener	194
		Charging	64
		Clock	244
		Combination Meter	274
		Cruise Control	202
		Door Lock Control and Wireless Door Lock Control	176
		Electronically Controlled Transmission and A/T Indicator	196
		Engine Control	68
		Headlight	82
		Interior Light	154
		Key Reminder and Seat Belt Warning	162
		Light Auto Turn Off	116
		Multiplex Communication System	138
		Power Window	168
		Theft Deterrent	186
15A	DOOR DL	Theft Deterrent	186
15A	FR FOG	Front Fog Light	88
15A	MIR HTR	Rear Window Defogger and Mirror Heater	270
15A	PWR OUTLET	Cigarette Lighter and Power Outlet	242
20A	D RR P/W	Multiplex Communication System	138
		Power Window	168
20A	P FR P/W	Multiplex Communication System	138
		Power Window	168
20A	P RR P/W	Multiplex Communication System	138
		Power Window	168
40A	HEATER	Automatic Air Conditioning	284

* These are the page numbers of the first page on which the related system is shown.

