


G ELECTRICAL WIRING ROUTING

Position of Parts in Engine Compartment



- A 1 A/C Ambient Temp. Sensor
- A 2 A/C Condenser Fan Motor
- A 3 A/C Magnetic Clutch and Lock Sensor
- A 4 A/C Triple Pressure SW
(A/C Dual and Single Pressure SW)
- A 7 ABS Speed Sensor Front LH
- A 8 ABS Speed Sensor Front RH
- A 9 Accel Position Sensor
- A10 Airbag Sensor Front LH
- A11 Airbag Sensor Front RH
- A31 ABS & BA & TRAC Actuator
- A32 ABS & BA & TRAC & VSC Actuator

- B 1 Brake Fluid Level Warning SW
- B 9 Back-Up Light SW

- C 1 Camshaft Position Sensor
- C 2 Camshaft Timing Oil Control Valve
- C 3 Crankshaft Position Sensor


- D 2 Daytime Running Light Relay No.3
- D 3 Daytime Running Light Relay No.4
- D 4 Daytime Running Light Resistor

- E 1 Electronically Controlled Transmission Solenoid
- E 3 Engine Control Module
- E 4 Engine Control Module
- E 5 Engine Control Module
- E 6 Engine Control Module
- E 7 Engine Control Module
- E 8 Engine Coolant Temp. Sensor
- E 9 Engine Hood Courtesy SW
- E10 Engine Oil Level Sensor
- E11 Engine Oil Pressure SW

- F 1 Front Fog Light LH
- F 2 Front Fog Light RH
- F 3 Front Parking Light LH
- F 4 Front Parking Light RH
- F 5 Front Side Marker Light LH
- F 6 Front Side Marker Light RH
- F 7 Front Side Turn Signal Light LH
- F 8 Front Side Turn Signal Light RH
- F 9 Front Turn Signal Light LH
- F10 Front Turn Signal Light RH
- F11 Front Wiper Motor
- F12 Fuel Pump Resistor
- F17 Front Window Deicer

- G 1 Generator
- G 2 Generator

Position of Parts in Engine Compartment



H 1 Headlight Beam Level Control Actuator LH
 H 2 Headlight Beam Level Control Actuator RH
 H 3 Headlight Cleaner Control Relay
 H 4 Headlight Cleaner Motor
 H 5 Headlight Control ECU LH
 H 6 Headlight Control ECU RH
 H 7 Headlight LH (High)
 H 8 Headlight RH (High)
 H 9 Heated Oxygen Sensor (Bank 1 Sensor 1)
 H10 Heated Oxygen Sensor (Bank 1 Sensor 2)
 H11 Heated Oxygen Sensor (Bank 2 Sensor 1)
 H12 Height Control Sensor Front LH
 H13 Horn LH
 H14 Horn RH

I 1 Igniter
 I 2 Ignition Coil No.1
 I 3 Ignition Coil No.2
 I 4 Ignition Coil No.3
 I 5 Injector No.1
 I 6 Injector No.2
 I 7 Injector No.3
 I 8 Injector No.4
 I 9 Injector No.5
 I 10 Injector No.6

J 1 Junction Connector
 J 2 Junction Connector
 J 3 Junction Connector
 J 4 Junction Connector

K 1 Keyless Buzzer
 K 2 Knock Sensor 1
 K 3 Knock Sensor 2

M 1 Mass Air Flow Meter

N 1 Noise Filter (Ignition)

O 1 O/D Direct Clutch Speed Sensor

P 1 Park/Neutral Position SW

P 2 Power Steering Oil Pressure Sensor

R 1 Radiator Fan Motor

S 1 Starter

S 2 Starter

T 1 Theft Deterrent Horn

T 2 Throttle Control Motor

T 3 Throttle Position Sensor

V 1 Vehicle Speed Sensor
(Electronically Controlled Transmission)

V 2 VSV (ACIS)

V 3 VSV (Canister Closed Valve)

V 4 VSV (EVAP)


V 9 Vehicle Speed Sensor (Combination Meter)

W 1 Washer Motor

W 2 Water Temp. SW

G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel




A12 A/C Control Assembly
 A13 A/C Control Assembly
 A14 A/C Room Temp. Sensor
 A15 A/C Solar Sensor
 A21 Air Inlet Control Servo Motor
 A22 Air Mix Control Servo Motor
 A23 Air Vent Mode Control Servo Motor
 A24 Airbag Squib (Front Passenger Airbag Assembly)
 A25 Airbag Squib (Steering Wheel Pad)
 A26 Antenna Amplifier
 A27 Ashtray Illumination
 A28 Automatic Light Control Sensor

B 2 Blower Motor
 B 3 Blower Motor Controller
 B 4 Blower Motor Controller
 B 5 Body ECU
 B 6 Body ECU
 B10 Brake Pedal Load Sensing SW

C 4 Center Airbag Sensor Assembly
 C 5 Center Airbag Sensor Assembly
 C 6 Center Airbag Sensor Assembly
 C 7 Cigarette Lighter
 C 8 Cigarette Lighter Illumination
 C 9 Combination Meter
 C10 Combination Meter
 C11 Combination SW
 C12 Combination SW
 C13 Combination SW
 C14 Clutch Start SW
 C15 Cruise Control Clutch SW
 C16 Curtain Shield Airbag Squib LH
 C17 Curtain Shield Airbag Squib RH

 D 5 Data Link Connector 3
 D 6 Daytime Running Light Relay (Main)
 D 7 Diode (A/C)
 D 8 Diode (Headlight Cleaner)
 D21 Diode (Fog Light)

Position of Parts in Instrument Panel



E 12 Electronically Controlled Transmission Pattern Select SW

G 3 Glove Box Light

H15 Headlight Beam Level Control ECU

H16 Headlight Cleaner SW

I 11 Ignition Key Cylinder Light

I 12 Ignition SW

J 5 Junction Connector

J 6 Junction Connector

J 7 Junction Connector

J 8 Junction Connector

J 9 Junction Connector

J 10 Junction Connector

J 19 Junction Connector

M 4 Multi-Display

M 5 Multi-Display

P 3 Parking Brake SW

P 4 Power Outlet

R 2 Radio and Player

R 4 Rheostat

R14 Rear Fog Light SW

R15 Remote Controller (Navigation)

S 3 Seat Heater SW (Driver's Seat)

S 4 Seat Heater SW (Front Passenger's Seat)

S 5 Shift Lock Control ECU

S 6 Stereo Component Amplifier

S 7 Stereo Component Amplifier

S 8 Stop Light SW

S15 Skid Control ECU

S16 Skid Control ECU

S17 Skid Control ECU

S18 Skid Control ECU

S19 Steering Sensor

T 5 Theft Deterrent ECU

T 6 Theft Deterrent ECU

T 7 TRAC Off SW

T 8 Transmission Control SW (L-2)

T 9 Transponder Key Amplifier

U 1 Unlock Warning SW


V10 VSC Warning Buzzer

Y 1 Yaw Rate Sensor

G ELECTRICAL WIRING ROUTING

Position of Parts in Body

[S/D]



A29 ABS Speed Sensor Rear LH

A30 ABS Speed Sensor Rear RH

B 7 Buckle SW LH

B 8 Buckle SW RH and
Seat Belt Warning Occupant Detection Sensor

D 9 Diode (Luggage Compartment Light)

D10 Door Courtesy Light Front LH

D11 Door Courtesy Light Front RH

D12 Door Courtesy SW Front LH

D13 Door Courtesy SW Front RH

D14 Door Courtesy SW Rear LH

D15 Door Courtesy SW Rear RH

D16 Door Lock Control SW RH

D17 Door Lock Motor and Door Lock Detection SW Front RH

D18 Door Lock Motor and Door Lock Detection SW Rear LH

D19 Door Lock Motor and Door Lock Detection SW Rear RH

D20 Door Lock Motor, Door Key Lock and Unlock SW and
Door Lock Detection SW Front LH

F13 Front Door Speaker LH

F14 Front Door Speaker RH

F15 Fuel Pump and Sender

F16 Fuel Sender (Sub)

H17 Heated Oxygen Sensor (Bank 2 Sensor 2)

H18 Height Control Sensor Rear LH

H19 High Mounted Stop Light

I 13 Interior Light

I 14 Inner Mirror

J 11 Junction Connector

J 12 Junction Connector

J 13 Junction Connector

J 14 Junction Connector

J 15 Junction Connector

J 16 Junction Connector

L 1 License Plate Light LH

L 2 License Plate Light RH

L 3 Light Failure Sensor

L 4 Luggage Compartment Door Courtesy SW and
Opener Motor


L 5 Luggage Compartment Door Key Unlock SW

L 6 Luggage Compartment Door Opener Relay

L 7 Luggage Compartment Light

Position of Parts in Body

[S/D]



M 2 Moon Roof Control ECU

M 3 Moon Roof Control SW

N 2 Noise Filter (Rear Window Defogger)

N 3 Noise Filter (Stop Light)

N 4 Navigation ECU

N 5 Navigation ECU

P 5 Personal Light

P 6 Power Window Control SW Front RH

P 7 Power Window Control SW Rear LH

P 8 Power Window Control SW Rear RH

P 9 Power Window Master SW

P10 Power Window Motor Front LH

P11 Power Window Motor Front RH

P12 Power Window Motor Rear LH

P13 Power Window Motor Rear RH

P14 Pretensioner LH

P15 Pretensioner RH

R 5 Rear Combination Light LH

R 6 Rear Combination Light LH

R 7 Rear Combination Light RH

R 8 Rear Combination Light RH

R 9 Rear Speaker and Woofer LH

R10 Rear Speaker and Woofer RH

R11 Remote Control Mirror LH

R12 Remote Control Mirror RH

R13 Remote Control Mirror SW

S 9 Seat Heater (Driver's Seat)

S10 Seat Heater (Front Passenger's Seat)

S11 Side Airbag Sensor LH

S12 Side Airbag Sensor RH

S13 Side Airbag Squib LH

S14 Side Airbag Squib RH

T12 Tweeter LH

T13 Tweeter RH

V 5 Vanity Light LH

V 6 Vanity Light RH

V 7 Vapor Pressure Sensor

V 8 VSV (Pressure Switching Valve)


W 3 Wireless Door Lock Control Receiver

W 4 Wire to FFC Holder

G ELECTRICAL WIRING ROUTING

Position of Parts in Body

[W/G]



A29 ABS Speed Sensor Rear LH

A30 ABS Speed Sensor Rear RH

B 7 Buckle SW LH

B 8 Buckle SW RH and
Seat Belt Warning Occupant Detection Sensor

B 11 Back Door Courtesy SW and Opener Motor

B12 Back Door Opener Relay

B13 Back Door Opener SW

D 9 Diode (Luggage Compartment Light)

D10 Door Courtesy Light Front LH

D11 Door Courtesy Light Front RH

D12 Door Courtesy SW Front LH

D13 Door Courtesy SW Front RH

D14 Door Courtesy SW Rear LH

D15 Door Courtesy SW Rear RH

D16 Door Lock Control SW RH

D17 Door Lock Motor and Door Lock Detection SW Front RH

D18 Door Lock Motor and Door Lock Detection SW Rear LH

D19 Door Lock Motor and Door Lock Detection SW Rear RH

D20 Door Lock Motor, Door Key Lock and Unlock SW and
Door Lock Detection SW Front LH

F 13 Front Door Speaker LH

F 14 Front Door Speaker RH

F 15 Fuel Pump and Sender

F 16 Fuel Sender (Sub)

H17 Heated Oxygen Sensor (Bank 2 Sensor 2)

H18 Height Control Sensor Rear LH

H19 High Mounted Stop Light

I 13 Interior Light

I 14 Inner Mirror

J 11 Junction Connector

J 13 Junction Connector

J 15 Junction Connector

J 16 Junction Connector

J 17 Junction Connector

J 18 Junction Connector

L 1 License Plate Light LH


L 2 License Plate Light RH

L 3 Light Failure Sensor

L 7 Luggage Compartment Light

Position of Parts in Body

[W/G]



M 2 Moon Roof Control ECU
M 3 Moon Roof Control SW

N 3 Noise Filter (Stop Light)
N 4 Navigation ECU
N 5 Navigation ECU

P 5 Personal Light
P 6 Power Window Control SW Front RH
P 7 Power Window Control SW Rear LH
P 8 Power Window Control SW Rear RH
P 9 Power Window Master SW
P 10 Power Window Motor Front LH
P 11 Power Window Motor Front RH
P 12 Power Window Motor Rear LH
P 13 Power Window Motor Rear RH
P 14 Pretensioner LH
P 15 Pretensioner RH
P 26 Power Outlet (Luggage)
P 27 Power Outlet Relay

R 5 Rear Combination Light LH
R 6 Rear Combination Light LH
R 7 Rear Combination Light RH
R 8 Rear Combination Light RH
R 11 Remote Control Mirror LH
R 12 Remote Control Mirror RH
R 13 Remote Control Mirror SW

R 16 Rear Side Marker Light
R 17 Rear Speaker LH
R 18 Rear Speaker RH
R 19 Rear Window Defogger
R 20 Rear Window Defogger
R 21 Rear Wiper Motor
R 22 Rear Wiper Motor

S 9 Seat Heater (Driver's Seat)
S 10 Seat Heater (Front Passenger's Seat)
S 11 Side Airbag Sensor LH
S 12 Side Airbag Sensor RH
S 13 Side Airbag Squib LH
S 14 Side Airbag Squib RH
S 20 Squawker LH
S 21 Squawker RH

T 12 Tweeter LH
T 13 Tweeter RH


V 5 Vanity Light LH
V 6 Vanity Light RH
V 7 Vapor Pressure Sensor
V 8 VSV (Pressure Switching Valve)

W 3 Wireless Door Lock Control Receiver
W 4 Wire to FFC Holder
W 5 Woofer

G ELECTRICAL WIRING ROUTING

Position of Parts in Seat

*1 : w/ Power Seat



B 7 Buckle SW LH
 B 8 Buckle SW RH and
 Seat Belt Warning Occupant Detection Sensor

S 9 Seat Heater (Driver's Seat)
 S10 Seat Heater (Front Passenger's Seat)

P16 Power Seat Control SW (Driver's Seat)
 P17 Power Seat Control SW (Front Passenger's Seat)
 P18 Power Seat Motor (Driver's Seat Front Vertical Control)
 P19 Power Seat Motor (Driver's Seat Rear Vertical Control)
 P20 Power Seat Motor (Driver's Seat Reclining Control)
 P21 Power Seat Motor (Driver's Seat Slide Control)
 P22 Power Seat Motor
 (Front Passenger's Seat Front Vertical Control)
 P23 Power Seat Motor
 (Front Passenger's Seat Rear Vertical Control)
 P24 Power Seat Motor
 (Front Passenger's Seat Reclining Control)
 P25 Power Seat Motor
 (Front Passenger's Seat Slide Control)

