


# CIGARETTE LIGHTER AND POWER OUTLET



## SERVICE HINTS

### C7 CIGARETTE LIGHTER

2-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position

1-GROUND : Always continuity

### P4 POWER OUTLET

1-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position

2-GROUND : Always continuity

## : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C7	<a href="#">34</a>	J10	<a href="#">35</a>	P26	<a href="#">39 (W/G)</a>
J5	<a href="#">35</a>	P4	<a href="#">35</a>	P27	<a href="#">39 (W/G)</a>

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	<a href="#">24</a>	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1E		
1G	<a href="#">24</a>	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2B	<a href="#">26</a>	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2G	<a href="#">26</a>	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2L	<a href="#">26</a>	Floor Wire and Passenger Side J/B (Right Kick Panel)

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH1	<a href="#">46</a>	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)

## : GROUND POINTS

Code	See Page	Ground Points Location
EC	<a href="#">42</a>	Left Fender Apron
ID	<a href="#">44</a>	Cowl Side Panel LH
IH	<a href="#">44</a>	Cowl Side Panel RH
BK	<a href="#">50 (W/G)</a>	Front Floor Panel RH

## : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	<a href="#">46</a>	Instrument Panel Wire	B7	<a href="#">50 (W/G)</a>	Floor Wire