


SEAT HEATER

FROM POWER SOURCE SYSTEM (SEE PAGE 56)

* 1 : W/ POWER SEAT
* 2 : W/O POWER SEAT



SERVICE HINTS

S3, S4 SEAT HEATER SW (DRIVER'S SEAT, FRONT PASSENGER'S SEAT)

3-GROUND : Approx. 12 volts with the ignition SW at **ON** position

2-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J7	35	S9	37 (S/D w/o Power Seat)	S10	37 (S/D w/o Power Seat)
S3	35		39 (W/G w/o Power Seat)		39 (W/G w/o Power Seat)
S4	35		40 (w/ Power Seat)		40 (w/ Power Seat)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1L	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB3	44	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
IH4	46	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
BG1	52	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)
BH1	52	Floor Wire and Front Seat RH Wire (Under the Front Passenger's Seat)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IH	44	Cowl Side Panel RH
BJ	48 (S/D)	Front Floor Panel LH
	50 (W/G)	
BK	48 (S/D)	Front Floor Panel RH
	50 (W/G)	