

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	C 4	Center Airbag Sensor Assembly	90980-11873
A 2	A/C Condenser Fan Motor	90980-11410	C 5	Center Airbag Sensor Assembly	90980-11872
A 3	A/C Magnetic Clutch and Lock Sensor	90980-11016	C 6	Center Airbag Sensor Assembly	90980-11871
A 4	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	90980-10943	C 7	Cigarette Lighter	90980-10760
A 7	ABS Speed Sensor Front LH	90980-11002	C 8	Cigarette Lighter Illumination	90980-11148
A 8	ABS Speed Sensor Front RH		C 9	Combination Meter	90980-11915
A 9	Accel Position Sensor	90980-11150	C10	Combination Meter	90980-11911
A10	Airbag Sensor Front LH	90980-11856	C11	Combination SW	90980-11672
A11	Airbag Sensor Front RH		C12	Combination SW	90980-11616
A12	A/C Control Assembly	90980-11973	C13	Combination SW	90980-11594
A13	A/C Control Assembly	90980-11971	C14	Clutch Start SW	90980-10825
A14	A/C Room Temp. Sensor	90980-10825	C15	Cruise Control Clutch SW	90980-10906
A15	A/C Solar Sensor	90980-11918	C16	Curtain Shield Airbag Squib LH	90980-11886
A21	Air Inlet Control Servo Motor	90980-11165	C17	Curtain Shield Airbag Squib RH	
A22	Air Mix Control Servo Motor		D 2	Daytime Running Light Relay No.3	90980-10939
A23	Air Vent Mode Control Servo Motor		D 3	Daytime Running Light Relay No.4	90980-10940
A24	Airbag Squib (Front Passenger Airbag Assembly)	90980-11886	D 4	Daytime Running Light Resistor	90980-10928
A25	Airbag Squib (Steering Wheel Pad)	90980-10850	D 5	Data Link Connector 3	90980-11665
A26	Antenna Amplifier	90980-10871	D 6	Daytime Running Light Relay (Main)	90980-11450
A27	Ashtray Illumination	90980-10825	D 7	Diode (A/C)	90980-11251
A28	Automatic Light Control Sensor	90980-11107	D 8	Diode (Headlight Cleaner)	
A29	ABS Speed Sensor Rear LH (S/D)	90980-11060	D 9	Diode (Luggage Compartment Light)	90980-10962
	ABS Speed Sensor Rear LH (W/G)	90980-10859	D10	Door Courtesy Light Front LH	90980-11148
A30	ABS Speed Sensor Rear RH (S/D)	90980-11299	D11	Door Courtesy Light Front RH	
	ABS Speed Sensor Rear RH (W/G)	90980-10824	D12	Door Courtesy SW Front LH	90980-10871
A31	ABS & BA & TRAC Actuator	90980-12020	D13	Door Courtesy SW Front RH	
A32	ABS & BA & TRAC & VSC Actuator		D14	Door Courtesy SW Rear LH	
B 1	Brake Fluid Level Warning SW	90980-11207	D15	Door Courtesy SW Rear RH	
B 2	Blower Motor	90980-10214	D16	Door Lock Control SW RH	90980-10797
B 3	Blower Motor Controller	90980-11667	D17	Door Lock Motor and Door Lock Detection SW Front RH	90980-11150
B 4	Blower Motor Controller	90980-11579	D18	Door Lock Motor and Door Lock Detection SW Rear LH	
B 5	Body ECU	90980-11911	D19	Door Lock Motor and Door Lock Detection SW Rear RH	
B 6	Body ECU	90980-11971	D20	Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front LH	90980-11858
B 7	Buckle SW LH (w/ Power Seat)	90980-11212	D21	Diode (Fog Light)	90980-10962
	Buckle SW LH (w/o Power Seat)	90980-10825	E 1	Electronically Controlled Transmission Solenoid	90980-11151
B 8	Buckle SW RH and Seat Belt Warning Occupant Detection Sensor	90980-11471	E 3	Engine Control Module	90980-12142
B 9	Back-Up Light SW	90980-11142	E 4	Engine Control Module	90980-12146
B10	Brake Pedal Load Sensing SW	90980-10860	E 5	Engine Control Module	90980-12143
B11	Back Door Courtesy SW and Opener Motor	90980-10795	E 6	Engine Control Module	90980-12145
B12	Back Door Opener Relay	82660-53010	E 7	Engine Control Module	90980-12144
B13	Back Door Opener SW	90980-10860	E 8	Engine Coolant Temp. Sensor	90980-10736
C 1	Camshaft Position Sensor	90980-10947	E 9	Engine Hood Courtesy SW	90980-11189
C 2	Camshaft Timing Oil Control Valve	90980-11162			
C 3	Crankshaft Position Sensor	90980-10947			

## L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
E10	Engine Oil Level Sensor	90980-11235	I 2	Ignition Coil No.1	90980-11246
E11	Engine Oil Pressure SW	90980-11363	I 3	Ignition Coil No.2	
E12	Electronically Controlled Transmission Pattern Select SW	90980-10933	I 4	Ignition Coil No.3	
F 1	Front Fog Light LH	90980-11096	I 5	Injector No.1	90980-11153
F 2	Front Fog Light RH		I 6	Injector No.2	
F 3	Front Parking Light LH	90980-11156	I 7	Injector No.3	
F 4	Front Parking Light RH		I 8	Injector No.4	
F 5	Front Side Marker Light LH	90980-11162	I 9	Injector No.5	
F 6	Front Side Marker Light RH		I10	Injector No.6	
F 7	Front Side Turn Signal Light LH	90980-11019	I11	Ignition Key Cylinder Light	90980-10906
F 8	Front Side Turn Signal Light RH		I12	Ignition SW	90980-11615
F 9	Front Turn Signal Light LH		I13	Interior Light	90980-10935
F10	Front Turn Signal Light RH		I14	Inner Mirror	90980-11950
F11	Front Wiper Motor	90980-11599	J 1	Junction Connector	90980-11661
F12	Fuel Pump Resistor	90980-10901	J 2	Junction Connector	
F13	Front Door Speaker LH	90980-10935	J 3	Junction Connector	90980-11542
F14	Front Door Speaker RH		J 4	Junction Connector	90980-10803
F15	Fuel Pump and Sender	90980-11077	J 5	Junction Connector	90980-10976
F16	Fuel Sender (Sub)	90980-11140	J 6	Junction Connector	82824-10020
F17	Front Window Deicer	90980-11295	J 7	Junction Connector	82824-16060
G 1	Generator	90980-09363	J 8	Junction Connector	
G 2	Generator	90980-11349	J 9	Junction Connector	82824-10030
G 3	Glove Box Light	90980-11098	J10	Junction Connector	82824-16060
H 1	Headlight Beam Level Control Actuator LH	90980-11144	J11	Junction Connector	82824-10010
H 2	Headlight Beam Level Control Actuator RH		J12	Junction Connector	90980-11542
H 3	Headlight Cleaner Control Relay	90980-10939	J13	Junction Connector	
H 4	Headlight Cleaner Motor	90980-11410	J14	Junction Connector	
H 5	Headlight Control ECU LH	90980-11255	J15	Junction Connector	90980-10976
H 6	Headlight Control ECU RH		J16	Junction Connector	90980-11542
H 7	Headlight LH (High)	90980-11095	J17	Junction Connector	90980-11915
H 8	Headlight RH (High)		J18	Junction Connector	90980-11542
H 9	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-11028	J19	Junction Connector	
H10	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-10869	K 1	Keyless Buzzer	90980-11142
H11	Heated Oxygen Sensor (Bank 2 Sensor 1)		K 2	Knock Sensor 1	90980-11166
H12	Height Control Sensor Front LH	90980-11016	K 3	Knock Sensor 2	
H13	Horn LH	90980-10619	L 1	License Plate Light LH	90980-11148
H14	Horn RH		L 2	License Plate Light RH	
H15	Headlight Beam Level Control ECU	90980-11469	L 3	Light Failure Sensor	90980-10803
H16	Headlight Cleaner SW	90980-11013	L 4	Luggage Compartment Door Courtesy SW and Opener Motor	90980-10825
H17	Heated Oxygen Sensor (Bank 2 Sensor 2)	90980-11028	L 5	Luggage Compartment Door Key Unlock SW	90980-11368
H18	Height Control Sensor Rear LH	90980-11860	L 6	Luggage Compartment Door Opener Relay	90980-10171
H19	High Mounted Stop Light (Bulb Type)	90980-11148	L 7	Luggage Compartment Light (S/D)	90980-11148
	High Mounted Stop Light (LED Type)	90980-11967		Luggage Compartment Light (W/G)	90980-10121
I 1	Igniter	90980-11653			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
M 1	Mass Air Flow Meter	90980-11317	R 4	Rheostat	90980-10908
M 2	Moon Roof Control ECU	90980-10801	R 5	Rear Combination Light LH	90980-11587
M 3	Moon Roof Control SW	90980-10367	R 6	Rear Combination Light LH	90980-10795
M 4	Multi-Display	90980-11877	R 7	Rear Combination Light RH	90980-11587
M 5	Multi-Display	90980-11923	R 8	Rear Combination Light RH	90980-10795
N 1	Noise Filter (Ignition)	90980-10843	R 9	Rear Speaker and Woofer LH	90980-11399
N 2	Noise Filter (Rear Window Defogger)	90980-11259	R10	Rear Speaker and Woofer RH	
N 3	Noise Filter (Stop Light)	90980-10825	R11	Remote Control Mirror LH	90980-11922
N 4	Navigation ECU	90980-11923	R12	Remote Control Mirror RH	
N 5	Navigation ECU	90980-11973	R13	Remote Control Mirror SW	90980-10801
O 1	O/D Direct Clutch Speed Sensor	90980-11156	R14	Rear Fog Light SW	90980-11533
P 1	Park/Neutral Position SW	90980-11784	R15	Remote Controller (Navigation)	90980-12012
P 2	Power Steering Oil Pressure Sensor	90980-10845	R16	Rear Side Marker Light	90980-11247
P 3	Parking Brake SW	90980-10871	R17	Rear Speaker LH	90980-10935
P 4	Power Outlet	90980-10860	R18	Rear Speaker RH	
P 5	Personal Light	90980-10935	R19	Rear Window Defogger	90980-11259
P 6	Power Window Control SW Front RH	90980-10797	R20	Rear Window Defogger	
P 7	Power Window Control SW Rear LH		R21	Rear Wiper Motor	90980-11296
P 8	Power Window Control SW Rear RH		R22	Rear Wiper Motor	90980-10871
P 9	Power Window Master SW	90980-11469	S 1	Starter	90980-11400
P10	Power Window Motor Front LH	90980-11011	S 2	Starter	90980-09531
P11	Power Window Motor Front RH	90980-10860	S 3	Seat Heater SW (Driver's Seat)	90980-10797
P12	Power Window Motor Rear LH		S 4	Seat Heater SW (Front Passenger's Seat)	
P13	Power Window Motor Rear RH		S 5	Shift Lock Control ECU	90980-11581
P14	Pretensioner LH	90980-11886	S 6	Stereo Component Amplifier	90980-10848
P15	Pretensioner RH		S 7	Stereo Component Amplifier	90980-11913
P16	Power Seat Control SW (Driver's Seat)	90980-10997	S 8	Stop Light SW	90980-11118
P17	Power Seat Control SW (Front Passenger's Seat)		S 9	Seat Heater (Driver's Seat)	90980-10905
P18	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825	S10	Seat Heater (Front Passenger's Seat)	
P19	Power Seat Motor (Driver's Seat Rear Vertical Control)		S11	Side Airbag Sensor LH	90980-11857
P20	Power Seat Motor (Driver's Seat Reclining Control)		S12	Side Airbag Sensor RH	
P21	Power Seat Motor (Driver's Seat Slide Control)		S13	Side Airbag Squib LH	90980-11864
P22	Power Seat Motor (Front Passenger's Seat Front Vertical Control)		S14	Side Airbag Squib RH	
P23	Power Seat Motor (Front Passenger's Seat Rear Vertical Control)		S15	Skid Control ECU	90980-11421
P24	Power Seat Motor (Front Passenger's Seat Reclining Control)		S16	Skid Control ECU	90980-11476
P25	Power Seat Motor (Front Passenger's Seat Slide Control)		S17	Skid Control ECU	90980-11637
P26	Power Outlet (Luggage)	90980-11300	S18	Skid Control ECU	90980-11638
P27	Power Outlet Relay	82660-20340	S19	Steering Sensor	90980-11581
R 1	Radiator Fan Motor	90980-10928	S20	Squawker LH	90980-11399
R 2	Radio and Player	90980-12038	S21	Squawker RH	
			T 1	Theft Deterrent Horn	90980-10619
			T 2	Throttle Control Motor	90980-10942
			T 3	Throttle Position Sensor	90980-10711
			T 5	Theft Deterrent ECU	90980-11392
			T 6	Theft Deterrent ECU	90980-11424

## L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
T 7	TRAC Off SW	90980-11013	V 5	Vanity Light LH	90980-11918
T 8	Transmission Control SW (L-2)	90980-11493	V 6	Vanity Light RH	
T 9	Transponder Key Amplifier	90980-10789	V 7	Vapor Pressure Sensor	90980-11860
T12	Tweeter LH	90980-11013	V 8	VSV (Pressure Switching Valve)	90980-11859
T13	Tweeter RH		V 9	Vehicle Speed Sensor (Combination Meter)	90980-11143
T14	TRAC Off SW and SNOW SW	90980-10933	V10	VSC Warning Buzzer	90980-10906
U 1	Unlock Warning SW	90980-10795	W 1	Washer Motor	90980-10981
V 1	Vehicle Speed Sensor (Electronically Controlled Transmission)	90980-11156	W 2	Water Temp. SW	90980-11235
V 2	VSV (ACIS)	90980-11149	W 3	Wireless Door Lock Control Receiver	90980-11909
V 3	VSV (Canister Closed Valve)	90980-11162	W 4	Wire to FFC Holder	82824-53010
V 4	VSV (EVAP)	90980-11156	W 5	Woofer	90980-10799
			Y 1	Yaw Rate Sensor	90980-12080

Note: Not all of the above part numbers of the connector are established for the supply.