


BACK-UP LIGHT

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



SERVICE HINTS

P1 (A) BACK-UP LIGHT SW [PARK/NEUTRAL POSITION SW] (A/T)

(A) 3—(A) 2 : Closed with the shift lever in **R** position

B9 (B) BACK-UP LIGHT SW (M/T)

(B) 2—(B) 1 : Closed with the shift lever in **R** position

○ : PARTS LOCATION

Code		See Page	Code		See Page	Code	See Page
B9	B	32	J15		38 (W/G)	R7	37 (S/D)
J1	A	33	P1	A	33		39 (W/G)
J2	B	33	R5		37 (S/D)		
J15		36 (S/D)			39 (W/G)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1I	24	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1K	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
BL	48 (S/D)	Left Quarter Panel LH
	50 (W/G)	