





THEFT DETERRENT






THEFT DETERRENT






THEFT DETERRENT



FROM POWER SOURCE SYSTEM (SEE PAGE 56)



THEFT DETERRENT

SERVICE HINTS

L5 LUGGAGE COMPARTMENT DOOR KEY UNLOCK SW

2-1 : Continuity with the door lock cylinder unlocked with the key

E9 ENGINE HOOD COURTESY SW

1-2 : Continuity with the engine hood open

D12, D13, D14, D15 DOOR COURTESY SW FRONT LH, RH, REAR LH, RH

1-GROUND : Continuity with the door open

D20 DOOR KEY LOCK AND UNLOCK SW AND DOOR LOCK DETECTION SW FRONT LH

4-2 : Continuity with the door lock cylinder locked with the key

3-2 : Continuity with the door lock cylinder unlocked with the key

B6 (B) BODY ECU

BECU-GROUND : Always approx. **12** volts

BSUB-GROUND : Always approx. **12** volts

ACC-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position

IG-GROUND : Approx. **12** volts with the ignition SW at **ON** position

GND-GROUND : Always continuity

GND2-GROUND : Always continuity

○ : PARTS LOCATION

Code		See Page	Code	See Page	Code		See Page
A12	A	34	D17	38 (W/G)	J15		38 (W/G)
A13	B	34	D18	36 (S/D)	J16		36 (S/D)
B5	A	34		38 (W/G)			38 (W/G)
B6	B	34	D19	36 (S/D)	J17		38 (W/G)
B11	B	38 (W/G)		38 (W/G)	K1		33
C9	A	34	D20	36 (S/D)	L4	A	36 (S/D)
C10	B	34		38 (W/G)	L5		36 (S/D)
D5		34	D21	34	M4		35
D12		36 (S/D)	E4	32	P9		37 (S/D)
		38 (W/G)	E9	32			39 (W/G)
D13		36 (S/D)	J5	35	T1		33
		38 (W/G)	J6	35	T5	A	35
D14		36 (S/D)	J7	35	T6	B	35
		38 (W/G)	J11	36 (S/D)	U1		35
D15		36 (S/D)		38 (W/G)	W3		37 (S/D)
		38 (W/G)	J12	36 (S/D)			39 (W/G)
D17		36 (S/D)	J15	36 (S/D)			

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room No.1 R/B (Engine Compartment Right)
2	22	Engine Room No.2 R/B (Engine Compartment Right)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1B	24	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1F	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1L		
1O	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2A	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2B		
2E	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2F		
2G		
2H		
2I		
2K	26	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)
2M	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
IA1	44	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IA3		
IB1	44	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
IG3	46	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IH1	46	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
II1	46	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BA1	48 (S/D)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
	50 (W/G)	
BB1	48 (S/D)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
	50 (W/G)	
BC2	48 (S/D)	Floor No.2 Wire and Floor Wire (Rear Floor Partition Panel RH)
	50 (W/G)	Floor No.2 Wire and Floor Wire (Rear Floor Partition Panel Center)

: GROUND POINTS

Code	See Page	Ground Points Location
EB	42	Center Side of the Intake Manifold
EC	42	Left Fender Apron
ID	44	Cowl Side Panel LH
IH	44	Cowl Side Panel RH
BK	48 (S/D)	Front Floor Panel RH
	50 (W/G)	
BL	48 (S/D)	Left Quarter Panel LH
	50 (W/G)	

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I2	46	Instrument Panel Wire	B4	50 (W/G)	Floor No.2 Wire
B4	48 (S/D)	Floor No.2 Wire	B7	50 (W/G)	Floor Wire