



F RELAY LOCATIONS


[Engine Compartment]




[Instrument Panel]



[Body]
(S/D)




(W/G)




F RELAY LOCATIONS

① : Engine Room No.1 R/B	Engine Compartment Right (See Page 20)
② : Engine Room No.2 R/B	




③ : Engine Room No.3 R/B	Engine Compartment Left (See Page 20)
--------------------------	---------------------------------------




F RELAY LOCATIONS

○ : Driver Side J/B

Left Kick Panel (See Page 20)







F RELAY LOCATIONS

○ : Passenger Side J/B

Right Kick Panel (See Page 20)




(Inner Circuit : See Page 29)



F RELAY LOCATIONS

[Driver Side J/B Inner Circuit]



[Passenger Side J/B Inner Circuit]

F RELAY LOCATIONS

[W4 : Wire to FFC Holder Inner Circuit]

