


GARAGE DOOR OPENER

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



SERVICE HINTS

V5 GARAGE DOOR OPENER [VANITY LIGHT LH]

1-GROUND : Always approx. 12 volts

2-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
V5	37 (S/D)	W4	37 (S/D)		
	39 (W/G)		39 (W/G)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1H	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1N	24	Roof Wire and Driver Side J/B (Left Kick Panel)
2H	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IJ1	46	Roof Wire and Floor No.2 Wire (Left Side of the Instrument Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
BJ	48 (S/D)	Front Floor Panel LH
	50 (W/G)	