




I GROUND POINT





I GROUND POINT



: PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
J1	A	33	J7	35	J16	36 (S/D)
J2	B	33	J11	36 (S/D)	W4	37 (S/D)
J3		33		38 (W/G)		39 (W/G)
J4		33	J15	36 (S/D)		
J5		35		38 (W/G)		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room No.1 R/B (Engine Compartment Right)
2	22	Engine Room No.2 R/B (Engine Compartment Right)
3	23	Engine Room No.3 R/B (Engine Compartment Left)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1B	24	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1F		
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1I	24	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1J	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1L		
2A	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2B		
2E	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2F		
2G		
2I		
2J		
2K	26	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)
2L	26	Floor Wire and Passenger Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
IA1	44	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IA3		
IF2	46	Instrument Panel Wire and A/C Sub Wire (Left Side of the Blower Unit)
IH1	46	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
II1	46	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IJ1	46	Roof Wire and Floor No.2 Wire (Left Side of the Instrument Panel)
BA1	48 (S/D)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
	50 (W/G)	
BB1	48 (S/D)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
	50 (W/G)	
BE1	48 (S/D)	Floor No.2 Wire and Luggage Room Wire (Near the License Plate Light LH)
BF1	48 (S/D)	Floor No.2 Wire and Luggage Room Wire (Near the License Plate Light RH)
BG1	52	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)
BH1	52	Floor Wire and Front Seat RH Wire (Under the Front Passenger's Seat)
BJ1	50 (W/G)	Back Door No.1 Wire and Floor No.2 Wire (Left Side of the Back Panel Upper)
BK2	50 (W/G)	Back Door No.1 Wire and Back Door No.2 Wire (Left Side of the Back Panel Lower)

I GROUND POINT



: GROUND POINTS

Code	See Page	Ground Points Location
EA	42	Front Side of the Intake Manifold
EB	42	Center Side of the Intake Manifold
EC	42	Left Fender Apron
ID	44	Cowl Side Panel LH
IE	44	Front Floor Panel Center LH
IF	44	Front Floor Panel Center RH
IG	44	Instrument Panel Reinforcement RH
IH	44	Cowl Side Panel RH
BJ	48 (S/D)	Front Floor Panel LH
	50 (W/G)	
BK	48 (S/D)	Front Floor Panel RH
	50 (W/G)	
BL	48 (S/D)	Left Quarter Panel LH
	50 (W/G)	
BM	50 (W/G)	Left Side of the Back Panel Upper
BN	50 (W/G)	Right Side of the Back Panel Lower



: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E2	42	Engine Room Main Wire	B3	48 (S/D)	Floor No.2 Wire
E3			B4	48 (S/D)	
E9				50 (W/G)	
I2	46	Instrument Panel Wire	B5	52	Front Seat LH Wire
I3			B6	52	Front Seat RH Wire
I5	46	Engine Room Main Wire	B7	48 (S/D)	Floor Wire
B2	48 (S/D)	Roof Wire		50 (W/G)	
	50 (W/G)		B8	50 (W/G)	Back Door No.2 Wire

