





# COMBINATION METER





# COMBINATION METER





# COMBINATION METER

## SERVICE HINTS

### P3 PARKING BRAKE SW

1-GROUND : Continuity with the parking brake lever pulled up

### F15 FUEL SENDER

2-3 : Approx. **2.0**  $\Omega$  at fuel full  
Approx. **55.0**  $\Omega$  at fuel empty

### C9 (A) COMBINATION METER

(A)17-GROUND : Approx. **12** volts with the ignition SW at **ON** position  
(A)18-GROUND : Always continuity  
(A)19-GROUND : Always continuity  
(A)15-GROUND : Always approx. **12** volts  
(A)16-GROUND : Always approx. **12** volts

## ○ : PARTS LOCATION

Code		See Page	Code	See Page	Code		See Page
A12	A	<a href="#">34</a>	E4	<a href="#">32</a>	J6	<a href="#">35</a>	
A13	B	<a href="#">34</a>	F15	<a href="#">36 (S/D)</a>	J7	<a href="#">35</a>	
B1		<a href="#">32</a>		<a href="#">38 (W/G)</a>	P3		<a href="#">35</a>
B5	A	<a href="#">34</a>	F16	<a href="#">36 (S/D)</a>	S15	A	<a href="#">35</a>
B6	B	<a href="#">34</a>		<a href="#">38 (W/G)</a>	S16	B	<a href="#">35</a>
C9	A	<a href="#">34</a>	J2	<a href="#">33</a>	T6		<a href="#">35</a>
C10	B	<a href="#">34</a>	J5	<a href="#">35</a>	V9		<a href="#">33</a>

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1F		
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1K	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2B	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2G		
2H		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA2	42	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
IA1	44	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IA3		
BC2	48 (S/D)	Floor No.2 Wire and Floor Wire (Rear Floor Partition Panel RH)
	50 (W/G)	Floor No.2 Wire and Floor Wire (Rear Floor Partition Panel Center)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
ID	44	Cowl Side Panel LH
IE	44	Front Floor Panel Center LH
IH	44	Cowl Side Panel RH

