


# TURN SIGNAL AND HAZARD WARNING LIGHT



## SERVICE HINTS

### FLSH RELAY

- 4-GROUND : Always approx. **12** volts
- 1-GROUND : Approx. **12** volts with the ignition SW at **ON** position
- 7-GROUND : Always continuity

## ○ : PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
A12	A	<a href="#">34</a>	F8	<a href="#">32</a>	J15	<a href="#">38 (W/G)</a>
A13	B	<a href="#">34</a>	F9	<a href="#">32</a>	R5	<a href="#">37 (S/D)</a>
B6		<a href="#">34</a>	F10	<a href="#">32</a>		<a href="#">39 (W/G)</a>
C9		<a href="#">34</a>	J5	<a href="#">35</a>	R7	<a href="#">37 (S/D)</a>
C11		<a href="#">34</a>	J7	<a href="#">35</a>		<a href="#">39 (W/G)</a>
F7		<a href="#">32</a>	J15	<a href="#">36 (S/D)</a>		

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room No.1 R/B (Engine Compartment Right)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1E		
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1I	24	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1K	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1L	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2A	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2B		
2F	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2H		
2I		

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	42	Left Fender Apron
ID	44	Cowl Side Panel LH
IH	44	Cowl Side Panel RH
BL	48 (S/D) 50 (W/G)	Left Quarter Panel LH

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E3	42	Engine Room Main Wire	I5	46	Engine Room Main Wire