



# ILLUMINATION





# ILLUMINATION

## SERVICE HINTS

### TAIL RELAY

3–5 : Closed with the light control SW at **TAIL** or **HEAD** position

### C11 LIGHT CONTROL SW [COMB. SW]

14–16 : Continuity with the light control SW at **TAIL** or **HEAD** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A12	<a href="#">34</a>	J5	<a href="#">35</a>	R15	<a href="#">35</a>
A27	<a href="#">34</a>	J7	<a href="#">35</a>	S3	<a href="#">35</a>
C8	<a href="#">34</a>	J8	<a href="#">35</a>	S4	<a href="#">35</a>
C9	<a href="#">34</a>	J9	<a href="#">35</a>	T5	<a href="#">35</a>
C11	<a href="#">34</a>	M4	<a href="#">35</a>	T7	<a href="#">35</a>
E12	<a href="#">35</a>	R2	<a href="#">35</a>	T8	<a href="#">35</a>
G3	<a href="#">35</a>	R4	<a href="#">35</a>	T14	<a href="#">35</a>
H16	<a href="#">35</a>	R14	<a href="#">35</a>		

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	<a href="#">22</a>	Engine Room No.1 R/B (Engine Compartment Right)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	<a href="#">24</a>	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1E		
1F		
1G	<a href="#">24</a>	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1O		
2B	<a href="#">26</a>	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	<a href="#">26</a>	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	<a href="#">42</a>	Left Fender Apron
ID	<a href="#">44</a>	Cowl Side Panel LH
IH	<a href="#">44</a>	Cowl Side Panel RH

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I3	<a href="#">46</a>	Instrument Panel Wire			

