



G ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness


▽ : Location of Ground Points



○ : Location of Splice Points




Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
EA1	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
EA2	
EA3	

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness



▽ : Location of Ground Points




Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
IA1	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IA3	
IB1	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
IB3	
IC1	Engine Room Main Wire and Floor No.2 Wire (Near the Driver Side J/B)
ID2	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IE1	Instrument Panel No.2 Wire and Instrument Panel Wire (Left Side of the Instrument Panel)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness



○ : Location of Splice Points



Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
IF1	Instrument Panel Wire and A/C Sub Wire (Left Side of the Blower Unit)
IF2	
IG1	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IG2	
IG3	
IH1	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
IH3	
IH4	
II1	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IJ1	Roof Wire and Floor No.2 Wire (Left Side of the Instrument Panel)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness

▽ : Location of Ground Points


[S/D]



○ : Location of Splice Points



Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
BA1	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BB1	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BC2	Floor No.2 Wire and Floor Wire (Rear Floor Partition Panel RH)
BD1	Sensor Wire and Floor No.2 Wire (Lower Back Panel LH)
BE1	Floor No.2 Wire and Luggage Room Wire (Near the License Plate Light LH)
BF1	Floor No.2 Wire and Luggage Room Wire (Near the License Plate Light RH)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness

▽ : Location of Ground Points


[W/G]



○ : Location of Splice Points




Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
BA1	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BB1	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BC2	Floor No.2 Wire and Floor Wire (Rear Floor Partition Panel Center)
BD1	Sensor Wire and Floor No.2 Wire (Lower Back Panel LH)
BJ1	Back Door No.1 Wire and Floor No.2 Wire (Left Side of the Back Panel Upper)
BJ2	
BK1	Back Door No.1 Wire and Back Door No.2 Wire (Left Side of the Back Panel Lower)
BK2	

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness



○ : Location of Splice Points



Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
BG1	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)
BH1	Floor Wire and Front Seat RH Wire (Under the Front Passenger's Seat)