



## SERVICE HINTS

### EFI RELAY

5-3 : Closed with the ignition SW at **ON** or **ST** position

### U1 UNLOCK WARNING SW

1-2 : Closed with the ignition key in the ignition key cylinder

## : PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
C9	A	34	J3	33		T9	35	
C10	B	34	J5	35		U1	35	
E3	A	32	J6	35				
E4	B	32	J7	35				

## : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room No.1 R/B (Engine Compartment Right)
2	22	Engine Room No.2 R/B (Engine Compartment Right)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2A	26	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2B		
2F	26	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2I		

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	44	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IA3		
IG3	46	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)

## : GROUND POINTS

Code	See Page	Ground Points Location
EC	42	Left Fender Apron
ID	44	Cowl Side Panel LH
IH	44	Cowl Side Panel RH

## : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I2	46	Instrument Panel Wire			