


BACK DOOR OPENER



SERVICE HINTS

B11 BACK DOOR COURTESY SW AND OPENER MOTOR

- 4—GROUND : Approx. 12 volts with the back door open operate
1, 3—GROUND : Always continuity

B13 BACK DOOR OPENER SW

- 1—2 : Continuity with the back door opener SW is pushed

: PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
B5	A	34	B12	38 (W/G)	J15	38 (W/G)
B6	B	34	B13	38 (W/G)	J17	38 (W/G)
B11		38 (W/G)	J5	35		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1I	24	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1L	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	44	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
BJ2	50 (W/G)	Back Door No.1 Wire and Floor No.2 Wire (Left Side of the Back Panel Upper)
BK1	50 (W/G)	Back Door No.1 Wire and Back Door No.2 Wire (Left Side of the Back Panel Lower)

: GROUND POINTS

Code	See Page	Ground Points Location
EC	42	Left Fender Apron
ID	44	Cowl Side Panel LH
BL	50 (W/G)	Left Quarter Panel LH
BN	50 (W/G)	Right Side of the Back Panel Lower

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B4	50 (W/G)	Floor No.2 Wire			