


REAR WIPER AND WASHER



SERVICE HINTS

W1 WASHER MOTOR

2-GROUND : Approx. **12** volts with the ignition SW at **ON** position

3-GROUND : Continuity with the rear wiper and washer SW at **WASH** position

R21 (A), R22 (B) REAR WIPER MOTOR

(A) 3-GROUND : Approx. **12** volts with the ignition SW at **ON** position

(B) 1-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C13	34	R21	A 39 (W/G)	W1	33
J5	35	R22	B 39 (W/G)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	44	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IB3	44	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
BJ2	50 (W/G)	Back Door No.1 Wire and Floor No.2 Wire (Left Side of the Back Panel Upper)
BK1	50 (W/G)	Back Door No.1 Wire and Back Door No.2 Wire (Left Side of the Back Panel Lower)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	42	Left Fender Apron
ID	44	Cowl Side Panel LH
BN	50 (W/G)	Right Side of the Back Panel Lower